



RIF./ Ref.	DESCRIZIONE / Description	QUANT.	CODICE / Code
1	PRESA DI FORZA Main drive	1	11820.212
2	ANELLO ELASTICO Ring for housing	1	515102.032
3	PERNO Shaft	2	11820.215
4	VITE Screw	1	516505.020
5	RASAMENTO Spacer	4	513505.006
6	INGRANAGGIO Idler gear	2	11820.213
7	ASTUCCIO A RULLINI Needle bearing	4	503101.006
8	BOCCOLA Spindle housing	2	11820.311
9	RALLA Washer	2	515201.013
10	GHIERA Nut	2	11820.214
11	VITE Screw	1	516404.005
12	VITE Screw	4	516403.003
13	VITE DI REGISTR. Adjuust. screw	2	413005.008-02
14	GHIERA Nut	2	414510.008
15	ANELLO ELASTICO Ring for shaft	1	515103.020
16	CUSCINET. A SFERE Ball bearing	1	501301.220
17	CORPO Main housing	1	11820.211
18	CUSCINET. A RULLINI Needle bearing	2	503101.005
19	CUSCINET. REGGISP. Thrust bearing	2	501401.005
20	RASAMENTO Spacer	2	11820.313
21	CUSCINET. A RULLINI Needle bearing	2	503201.006
22	ANELLO ELASTICO Ring for housing	2	515104.012
23	GUARNIZIONE Seal	2	514132.006
24	PORTA PINZA Collet holder	2	413005.008-01
25	MANDRINO Spindle	2	11820.312
26	INGRASSATORE Ball spring lubricator	1	509101.006